


ISTRUZIONI INSTALLAZIONE - INSTALLING INSTRUCTIONS - INSTRUCTIONS DE MONTAGE

CAUTION : BEFORE STARTING, TURN OFF POWER OF MAIN CIRCUIT PANEL



DIMENSIONI mm / DIMENSIONS mm

ATTACCO AGGIUNTIVO (SUGGERITO)
4 viti atufilettanti del 3,9ADDITIONAL ATTACK (suggested)
4 self - screwing screws D 3.9