



ALL OPERATIONS MUST BE CARRIED OUT BY QUALIFIED PERSON

ASSEMBLY and ON SWITCHING




- 1) Fasten the light source.
Fasten the cylinder with the light source to the cylinder slot on the upper part of the lamp.




- 2) Rotate the light source.
The cylinder with the light source has two positions: the first one is "off", the second one at the end of rotation is "on".

OFF SWITCHING and DISMANTING



- 3) Rotate the cylinder with the light source until the first click.
The first click is the "off" position.
Rotate until you reach the extraction position.



- 4) Unfasten the cylinder with the light source.
Pull the cylinder with the light source, which easily come off the cylinder in the upper part of the lamp.

ALL OPERATIONS MUST BE CARRIED OUT BY QUALIFIED PERSON

CHARGING



5) Plug the charger in.



6) Position the cable as shown in the image.

	GREEN LED	RED LED
USB connected battery not inserted	●	Fast flashing 
USB connected discharged battery inserted	○	●
USB connected full charged battery inserted	●	○