

INSTALLING INSTRUCTIONS


Pag. 1/2

DRAWN BY N.O.

ALL OPERATIONS MUST BE CARRIED OUT BY QUALIFIED PERSON


- ① Separate the lamp from the bracket removing the screws.

Separare la lampada dalla staffa rimuovendo le viti.




- ② Fix the bracket on the ceiling (use appropriate anchors depending on the type of ceiling)

Fissare la staffa a soffitto (utilizzare tasselli appropriati in base al tipo di soffitto).



- ③ Connect the lamp to the main power following the sketch.

Connettere la lampada all'impianto elettrico seguendo lo schema.



INSTALLING INSTRUCTIONS


Pag. 2/2

DRAWN BY N.O.

ALL OPERATIONS MUST BE CARRIED OUT BY QUALIFIED PERSON



- ④ Fix the lamp to the bracket using the screws provided.


Fissare la lampada alla staffa usando le viti fornite.



- ⑤ Plug the diffuser in the proper position on the lamp.


Incastrare il diffusore nell'apposito alloggiamento sulla lampada.




TRIDONIC


Installation / wiring

Circuit diagram



Wiring type and cross section

The wiring can be in stranded wires with ferrules or solid with a cross section of 0.2–1.5 mm².


Strip 8.5–9.5 mm of insulation from the cables to ensure perfect operation of the push-wire terminals.

Use one wire for each terminal connector only.

Use each strain relief channel for one cable only.


LED module/LED Driver/supply

wire preparation:
0.2 – 1.5 mm²



Loose wiring

Press down the "push button" and remove the cable from front.



Wiring guidelines

- The cables should be run separately from the mains connections and mains cables to ensure good EMC conditions.
- The LED wiring should be kept as short as possible to ensure good EMC. The max. secondary cable length is 2 m (4 m circuit), this applies for LED output as well as for I-select 2.

For wiring in dimming operation with ready2mains refer to the ready2mains Gateway datasheet.